



Adtec device Boot Key

The boot key is designed to lock the Adtec device into its boot mode. During the boot mode the player has IO functionality limited to RS232 serial communications.

Instructions for use:

1. Place the boot key on the parallel port
2. Reset the device by holding the Reset button for 1 second or power off and back on.
3. The device will restart in boot mode only.

Boot Mode RS232 Settings

Baud Rate	Data Bits	Parity	Stop Bit
115,200	8	1	N

Boot Key

Boot Key Configuration	Pin 4	Pin 9	Status
Short	D1	CA	Short

Adtec device Configuration Key

The configuration key is designed to reset Adtec devices to the factory configuration.

Instructions for use:

4. Place the configuration key on the parallel port
5. Reset the device by holding the Reset button for 1 second or power off and back on.
6. The device will restart with the configuration back to factory default.

Configuration Key

CFG key Configuration	Pin 5	Pin 9	Status
Short	D0	CA	Short