

Getting Started

Thank you for your purchase of the Adtec Soloist 4111. This quick start guide should help you with your initial setup. Advanced users can find direct API command help as part of the on-board web application. You can view it by looking for the HELP tab once your unit is powered up and you are connected to the web-application. See back for more details.

Front Panel LEDs:

Play

- No Decoder Activity
- Active Decode

Audio

- No Audio Decoding
- Active Audio Decoding

Multicast

- Playing from Hard Drive
- Multicast Receiving

Display Target



- Indicates current display target
NTSC, PAL, 720, 1080, Other

Video

- No Video Decoding
- Active Video Decoding

Alarm

- Decoder Alarm



System LED Status

Power

- Power is OFF
- Power is ON

Busy

- No Network Traffic
- Network Traffic Present

Alarm

- No System Alarm
- Minor Alarm
- Major Alarm

Storage

- Not Currently Used

Link

- No Link Detected
- Link Active

Additional support can be provided through our Customer Support Department.

Telephone: 615.256.6619

Email: support@adtecinc.com

Internet: www.adtecinc.com/supportrequest/

The most recent firmware is available on our support website www.adtecinc.com.

Units ship with the front panel logged in by default. If you become logged out and are prompted for a password, use the following key sequence for access.
 Press <Select> when panel displays 'User Login -- logged out'
 Press <Up arrow>
 Press <Select>
 Press <Enter>
 Press <Right arrow>
 Press <Enter>