

### Getting Started

Thank you for your purchase of the Adtec Soloist-HD Pro. This quick start guide should help you with your initial setup. Further instructions are available via the manual located on our support website, [www.adtecinc.com/support](http://www.adtecinc.com/support). Advanced users can find direct API command help as part of the on-board web application. You can view it by looking for the HELP tab once your unit is powered up and you are connected to the web-application. See back for more details.

### Front Panel LEDs:

#### Play

- No Decoder Activity
- Active Decode

#### Audio

- No Audio Decoding
- Active Audio Decoding

#### Mode

- Playing from Hard Drive
- DVB-ASI Receiving
- Multicast Receiving

#### Display Target


- Indicates current display target  
NTSC, PAL, 720, 1080, Other

#### Video

- No Video Decoding
- Active Video Decoding

#### Alarm

- Decoder Alarm



### System LED Status

#### Power

- Power is OFF
- Power is ON

#### Alarm

- No System Alarm
- Minor Alarm
- Major Alarm

#### Link

- No Link Detected
- Link Active

#### Busy

- No Network Traffic
- Network Traffic Present

#### Storage

- Not Currently Used

Additional support can be provided through our Customer Support Department.

**Telephone:** 615.256.6619

**Email:** [support@adtecinc.com](mailto:support@adtecinc.com)

**Internet:** [www.adtecinc.com/supportrequest/](http://www.adtecinc.com/supportrequest/)

The most recent firmware is available on our support website [www.adtecinc.com](http://www.adtecinc.com).

Units ship with the front panel logged in by default. If you become logged out and are prompted for a password, use the following key sequence for access.  
Press <Select> when panel displays 'User Login -- logged out'  
Press <Up arrow>  
Press <Select>  
Press <Enter>  
Press <Right arrow>  
Press <Enter>